Instructions

309398
Rev. A

Read and keep for reference. For detailed instructions and warnings, see manual 309301.

GRACO
First choice when quality counts™

Software Upgrade Kit 245248

For upgrading ProDispense™ main PCB board software

To avoid damage, keep main PCB chip in its original packaging until you are ready to use it. Ground yourself with the wrist strap before handling circuit board components.

Kit includes:

Description	Qty.
Main PCB Chip with software update	1
Chip Extractor Tool	1
Grounding Wrist Strap	1

Replacing Main PCB Chip

To reduce the risk of fire, explosion or electric shock:

- ProDispense controller must only be installed and serviced by a qualified electrician.
- Turn off ProDispense power switch and disconnect electrical power supply before servicing equipment.

1. Turn off ProDispense power switch.
2. Remove control box cover (A). See Manual 309301 and refer to **FIG. 2**.
3. Locate PCB chip (B) on main circuit board. See **FIG. 1**.
4. Remove old chip (B) with chip extractor provided.

The chip has three sharp corners and one chamfered corner. Orient the chip's chamfered corner toward the socket's chamfered corner. Incorrect installation can damage the chip or board.

5. Orient the new chip with the main PCB socket and lay it on the socket. With even pressure, snap the chip firmly into place. When properly installed, the top of the chip is flush with the top of the socket.
6. Reinstall control box cover.



FIG. 1

COPYRIGHT 2001, Graco Inc.
Graco Inc. is registered to I.S. EN ISO 9001



FIG. 2

Sales Offices: Minneapolis, Detroit
International Offices: Belgium, Korea, Hong Kong, Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441
www.graco.com
PRINTED IN USA 309398 July 2001